
## Dual-SIM Card - Instruction

## 1. Two SIM cards in one iPhone, single standby


- 2. Auto-switch between SIM cards
- 3. Enable to edit switching time
- 4. Enable to edit display name of SIM which can be showed on iPhone screen.

Features:

Installation:





































4. Fold the flexible PCB and insert into iPhone

5. Insert into side slot of iPhone

•

6. Put case on

ത-ം

**=** 

(**⊚**-∞)











Set Number

Instruction:

"SIMore"menu:

Switch Number

1. Enter Setting - Phone - SIM Applications, it shows

Switch Number:

Short key function:

the following short codes: Dial #11 to select SIM-1

Dial #22 to select SIM-2 Dial #99 to pop up SIMore menu.

Set Number:

Manual switching between SIM-1 to SIM-2

You can switch between SIMs by dialling


Name SIM-1: Change name for SIM-1


Name SIM-2: Change name for SIM-2 Name SIM cards (SIM1 & SIM2) with number only. (Defaut SIM cards name are SIM-1 & SIM-2). Reset: press to reset SIM's name to default.


Select SIM-1 to activate SIM-1

Select SIM-2 to activate SIM-2













Content:

Notes:

·Dual SIM Adapter × 1



Please restart iPhone if no network's signal after switching.